Technical data sheet

LMB24-IP

Proportional, Non-Spring Return, 24 V, Cloud, BACnet/IP, Modbus TCP

- Torque motor 5 Nm
- Nominal voltage AC/DC 24 V
- Control modulating, Cloud, communicative, Hybrid
- Conversion of sensor signals
- Communication via BACnet IP, Modbus TCP and Cloud





5-year warranty









Technical data		
Electrical data	Nominal voltage	AC/DC 24 V
	Nominal voltage frequency	50/60 Hz
	Nominal voltage range	AC 19.228.8 V / DC 21.626.4 V
	Power consumption in operation	3 W
	Power consumption in rest position	3 W
	Power consumption for wire sizing	4.5 VA
	Transformer sizing	4.5 VA (class 2 power source)
	Electrical Connection	18 GA appliance cable, 1/2" conduit connector and RJ45 socket (ethernet)
	Overload Protection	electronic throughout 095° rotation
Functional data	Torque motor	5 Nm
	Communicative control	Cloud
		BACnet IP
		Modbus TCP
	Operating range Y	210 V
	Operating range Y note	Hybrid via 210 V
	Operating range Y variable	0.510 V
	Position accuracy	±5%
	Direction of motion motor	selectable with switch 0/1
	Manual override	external push button
	Angle of rotation	Max. 95°
	Angle of rotation note	adjustable with mechanical stop
	Running Time (Motor)	150 s / 95°
	Running time motor variable	70220 s
	Adaptation Setting Range	manual
	Noise level, motor	35 dB(A)
	Mechanical interface	Universal shaft clamp 620 mm
	Position indication	Mechanically, 3065 mm stroke
Safety data	Protection class IEC/EN	III, Safety Extra-Low Voltage (SELV)
•	Degree of protection IEC/EN	IP54
	Degree of protection NEMA/UL	NEMA 1
	Enclosure	UL Enclosure Type 1
		21

**EMC** 

CE according to 2014/30/EU



	Technical data sheet	LMB24-IP
Safety data	Agency Listing	cULus acc. to UL60730-1A/-2-14, CAN/CSA E60730-1:02, CE acc. to 2014/30/EU and 2014/35/EU; Listed to UL 2043 - suitable for use in air plenums per Section 300.22(c) of the NEC and Section 602.2 of the IMC
	Quality Standard	ISO 9001
	Mode of operation	Type 1
	Rated impulse voltage supply / control	0.8 kV
	Ambient temperature	-22122°F [-3050°C]
	Storage temperature	-40176°F [-4080°C]
	Ambient humidity	Max. 95% RH, non-condensing
	Servicing	maintenance-free

### **Product features**

#### **Application**

Materials

Housing material

For proportional modulation of dampers in HVAC systems. Actuator sizing should be done in accordance with the damper manufacturer's specifications.

UL94-5VA

The actuator is controlled via the Belimo Cloud, BACnet/IP or Modbus TCP and drives to the position defined by the control variable. Multiple data points can be written and read via the control interface.

Local control mode: the actuator receives an analog control signal from a conventional controller and drives to the control position. In addition, using the Belimo Cloud, BACnet/IP or Modbus TCP, various data points can be read and with the exception of the control signal written to the actuator. This Belimo Cloud connected damper actuator has two universal sensor inputs ready for your innovative HVAC applications.

The two universal sensor inputs (passive, active, or contact) serve as an analogue/digital converter for the digital transmission of the sensor value to a higher level system. Selecting the sensor type is accomplished via connection to the integrated web server (RJ45 connection to the web browser) or directly via the Belimo Cloud. The actuators performance and sensor data is recorded locally with 13 months of storage. This data can be used for analytical purposes, downloaded via csv files, or used in your HVAC application.

## Converter for sensors

Connection option for two sensors (passive sensor, active sensor or switching contact). The actuator serves as an analog/digital converter for the transmission of the sensor signal to the higher level system.

## Communication

The configuration can be carried out through the integrated web server (RJ45 connection to the web browser), by communicative means or via the Cloud.

Additional information regarding the integrated web server can be found in the separate documentation.

## Positioning signal inversion

This can be inverted in cases of control with an analog positioning signal. The inversion causes the reversal of the standard behavior, i.e. for control signal 0%, the actuator is opened to max and for control signal 100%, the actuator is closed.



## Technical data sheet

LMB24-IP

#### **Application**

For proportional modulation of dampers in HVAC systems. Actuator sizing should be done in accordance with the damper manufacturer's specifications.

The actuator is controlled via the Belimo Cloud, BACnet/IP or Modbus TCP and drives to the position defined by the control variable. Multiple data points can be written and read via the control interface.

Local control mode: the actuator receives an analog control signal from a conventional controller and drives to the control position. In addition, using the Belimo Cloud, BACnet/IP or Modbus TCP, various data points can be read and with the exception of the control signal written to the actuator. This Belimo Cloud connected damper actuator has two universal sensor inputs ready for your innovative HVAC applications.

The two universal sensor inputs (passive, active, or contact) serve as an analogue/digital converter for the digital transmission of the sensor value to a higher level system. Selecting the sensor type is accomplished via connection to the integrated web server (RJ45 connection to the web browser) or directly via the Belimo Cloud. The actuators performance and sensor data is recorded locally with 13 months of storage. This data can be used for analytical purposes, downloaded via csv files, or used in your HVAC application.

## Simple direct mounting

Simple direct mounting on the damper shaft with a universal shaft clamp, supplied with an antirotation device to prevent the actuator from revolving.

### Data recording

The recorded data (integrated data recording for 13 months) can be used for analytical purposes.

Download csv files via web browser.

#### Manual override

Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).

#### Adjustable angle of rotation

Adjustable angle of rotation with mechanical end stops.


## High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.

## Home position

The first time the supply voltage is switched on, i.e. at the time of commissioning, the actuator carries out an adaptation, which is when the operating range and position feedback adjust themselves to the mechanical setting range.

The actuator then moves into the position defined by the positioning signal.



# Adaptation and synchronisation

An adaption can be triggered manually by pressing the "Adaption" button. Both mechanical end stops are detected during adaption for setting the mechanical working range. The actuators operating range and runtime are scaled to this working range.



# Accessories

Electrical accessories	Description	Туре
	Positioner for front-panel mounting	SGF24
	Positioner for wall mounting	SGA24
	Resistor, 500 $\Omega$ , 1/4" wire resistor with 6" pigtail wires	ZG-R01
	Cable Gland	43442-00001
	(NEMA 4 models)	
	Cable conduit connector 1/2"	TF-CC US
	Transformer, AC 120 V to AC 24 V, 40 VA	ZG-X40
	Battery, 12 V, 1.2 Ah (two required)	NSV-BAT
	Battery backup system, for non-spring return models	NSV24 US
	Feedback potentiometer 15 kΩ gray	P15000A-F GR
	Feedback potentiometer 10 k $\Omega$ add-on, grey	P10000A GR
	Feedback potentiometer 5 k $\Omega$ add-on, grey	P5000A GR
	Feedback potentiometer 2.8 kΩ add-on, grey	P2800A GR
	Feedback potentiometer 1 k $\Omega$ add-on, grey	P1000A GR
	Feedback potentiometer 500 Ω add-on, grey	P500A GR
	Feedback potentiometer 140 Ω add-on, grey	P140A GR
	Auxiliary switch, mercury-free Auxiliary switch, mercury-free	P475-1 P475
	Auxiliary switch, mercury-free Auxiliary switch 2 x SPDT add-on	S2A
	Auxiliary switch 1 x SPDT add-on	S1A
Mechanical accessories	Description	Туре
Mechanical accessories		
	Damper crank arm Slot width 6.2 mm, clamping range Ø1018 mm Damper crank arm Slot width 8.2 mm, clamping range Ø1018 mm	KH6 KH8
	Damper crank arm Slot width 8.2 mm, clamping range Ø1425 mm	KH10
	Damper crank arm Slot width 8.2 mm, for Ø1.05"	KH10 KH12
	Ball joint suitable for damper crank arm KH8, Multipack 10 pcs.	KG6
	Ball joint suitable for damper crank arm KH8, Multipack 10 pcs.	KG8
	Ball joint suitable for damper crank arm KH8 / KH10, Multipack 10 pcs.	KG10A
	Push rod for KG6 & KG8 ball joints (36" L, 5/16" diameter).	SH8
	Push rod for KG10A ball joint 36" L, 3/8" diameter	SH10
	Damper clip for damper blade, 3.5" width.	ZG-DC1
	Damper clip for damper blade, 6" width.	ZG-DC2
	Weather shield 330x203x152 mm [13x8x6"] (LxBxH)	ZS-100
	Base plate, for ZS-100	ZS-101
	Weather shield 406x213x102 mm [16x8-3/8x4"] (LxWxH)	ZS-150
	Shaft extension 240 mm Ø20 mm for damper shaft Ø 822.7 mm	AV8-25
	Anti-rotation bracket TF/NKQ/AM/NM/LM.	TF-P
	17" Mounting Bracket for AF,NF,GM,AM,SM	ZG-100
	Mounting Bracket: AF,NF,LF,GM,AM,NM,SM	ZG-101
	Wrench 0.32 in and 0.39 in [8 mm and 10 mm]	TOOL-06
	Adapter for auxiliary switch and feedback potentiometer	Z-SPA
	LMB(X) clamp (3/8")	K-LM10
	LMB(X) clamp (1/2").	K-LM12
	Standard LMB(X) clamp (5/8").	K-LM16
	LMB(X) clamp (3/4").	K-LM20
	Shaft extension for 1/2" diameter shafts (3" L).	ZG-LMSA
	Shaft extension for 3/8" diameter shafts (4" L).	ZG-LMSA-1
	Shaft extension for 1/2" diameter shafts (5" L).	ZG-LMSA-1/2-5
	Shaft extension 170 mm Ø10 mm for damper shaft Ø 616 mm Mounting plate for SGF.	AV6-20 ZG-SGF
Service tools	Description	Type
Sei vice tools		PS-100
	Signal simulator, Power supply AC 120 V	r3-100


# **Electrical installation**



Supply from isolating transformer.

Parallel connection of other actuators possible. Observe the performance data.





Initial ethernet connection and set-up

Cable colors:

1 = black

2 = red

5 = orange

10 = yellow-black

11 = yellow-pink

12 = yellow-grey

## **Functions**



The connection diagrams shows connections for the first sensor on terminal S1, while the second sensor can be connected identically on terminal S2.

Parallel use of different sensor types is permitted.

For hybrid operation, S1 is used for the control signal Y and must be configured as an active sensor.

## **Dimensions**

